








de Raumbediengerät
 fr Thermostat
 en Wireless room thermostat
 it Dispositivo di controllo ambientale
 es Termóstato ambiente
 sv Wave Termostat
 nl Draadloze kamerthermostaat

Montagevorschrift
 Instruction de montage
 Fitting instructions
 Istruzioni di montaggio
 Instrucciones de montaje
 Monteringsanvisning
 Montagevoorschrift


LRT410RK104

de Installationsanweisung für die Elektrofachkraft
 fr Notice d'installation pour l'électricien
 en Guidelines for the electrician
 it Istruzioni per l'installazione per elettricisti esperti
 es Instrucciones para el electricista
 sv Installationsanvisning för installatör och elektriker
 nl Installatieinstructies voor de elektrovakman

de Für den Einsatz in üblicher Umgebung
 fr Pour usage dans un environnement normal
 en For use in normal environment
 it Per l'impiego in ambienti comuni
 es Para el uso en ambiente normal
 sv För placering i normal miljö
 nl Voor gebruik in normale omgevingen




6




B12517

7




B12518

8



B12519

9



B12520a

de Sollwert einstellen
 fr Configurer la valeur de consigne
 en Set setpoint
 it Impostazione del valore nominale
 es Ajustar el valor nominal
 sv Ställ in önskad temperatur
 nl Referentiewaarde instellen



de www.sauter-controls.com ➔ Produkte ➔ MD Datenblatt.
 fr www.sauter-controls.com ➔ Produits ➔ Fiche MD.
 en www.sauter-controls.com ➔ Products ➔ MD Datasheet.
 it www.sauter-controls.com ➔ Products ➔ MD Datasheet.
 es www.sauter-controls.com ➔ Products ➔ MD Datasheet.
 sv www.sauter-controls.com ➔ Products ➔ MD Datasheet.
 nl www.sauter-controls.com ➔ Products ➔ MD Datasheet.

de Dokument aufbewahren
 fr Ce document est à conserver
 en Retain this document
 it Conservare il documento
 es Guardar el documento
 sv Spara dokumentationen
 nl Document bewaren

© Fr. Sauter AG
 Im Surinam 55
 CH-4016 Basel
 Tel. +41 61 - 695 55 55
 Fax +41 61 - 695 55 10
www.sauter-controls.com
info@sauter-controls.com